



Alcatel One Touch Fierce Rear Facing Camera Replacement

In this guide we showed how to carefully remove the main camera from you phone in order to replace it.

Written By: Cody Stouffer



INTRODUCTION

Use this guide to replace the rear facing camera on your Alcatel One Touch Fierce.

TOOLS:


- [iFixit Opening Tools](#) (1)
 - [Phillips #000 Screwdriver](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Rear Case




- Pry with a plastic opening tool, or your fingernail, in the divot at the bottom left corner of the phone.
- Lift the rear case by the corner nearest the divot and remove it from the phone.

Step 2 — Midframe



- Remove the 11 Phillips #000 screws.
- The midframe should lift free.

Step 3 — Rear Facing Camera



- Use a pair of tweezers to gently disconnect the camera connector and remove the rear facing camera.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-20 02:21:16 PM.